## LX Power Module

The LX Series Power Module makes it easy to connect more heating mats or cables to the same thermostat without the need for contactor panels.

- An easy control solution for large areas
- · Receives on/off command from the main thermostat
- Each Power Module adds 15A switching capability
- Up to 5 Power Modules can be added to the thermostat
- Includes Class-A GFCI for safety (approved for wet locations)
- For use with Programmable LX thermostat only

Ordering I	nformation Power Module /	Power Module / Contactor			
Part No.	Description	Max. Amps	Coil Voltage	No. of Contactors	
088L5135	Power Module with GFCI	15	N/A	1	
088L3450	Single Contactor, 600V max.	40	120	1	
088L3451	Single Contactor, 600V max.	40	208-240	1	

Contactor or LX Power Module is required for loads exceeding 15 Amps on a single thermostat All contactors are complete with NEMA 1 enclosure



Cable Strapping



. . . . .

Little Buzzer



Sensor Conduit



LX Repair Kit



Floor Sensor



## **Electric Floor Heating Accessories**

Ordering Information LX Accessories					
Part No.	Description				
088L1050	Cable Strapping (15 ft/4.5 m)				
088L1054	Cable Strapping (75 ft/22.9 m)				
088L3008	Replacement floor sensor for LX Thermostat				
088L0014	LX Repair Kit (includes: crimp connectors, repair wire, heat shrink, tubes)				
19809099	Sensor Conduit (8 ft)				
088L0028	Little Buzzer (continuity alarm)				

## Little Buzzer - Continuity Alarm (088L0028)

Simplify your installation process by using the Little Buzzer by Danfoss. The Little Buzzer is designed to monitor Danfoss Heating Mats or Cables during installation and will sound an alarm if the heating element is cut or damaged. This allows an easy repair before the floor covering is laid. The Little Buzzer is battery powered with a set of batteries included.

NOTE: A continuity alarm does not replace the need for measuring and verifying the Ohm resistance three times throughout the installation process. Failure to do so may result in voiding the warranty.